









## Technical Data Sheet Ice Machine Disinfectant ICT06



Fast dissolving - Biodegradable - Safe alternative to bleach.

## **DIRECTIONS**

- Wear gloves & eye protection when handling tablets.
- Set Ice machine to cleaning cycle.
- Add 1 tablet, per litre of water in cycle (See Mfrs Guide) to water tank.

Follow manufacturers cleaning cycle instructions.

Each tablet will deliver 1,000 ppm Chlorine content in one litre of water.

**BSEN** 1276

FOOD AREA

BSEN 13697

Store in cool conditions away from direct sunlight Avoid extremes of temperature Keep out of reach of children Use within 6 months of opening Shelf life 36 months

## **SPECIAL FEATURES**

- An easy way to provide a consistent level of chlorine in bacteria killing operations.
- Effective for general disinfecting and can be used on the ice collection bin and all machine surfaces.
- Has passed the European Suspension Test BSEN 1276 / European Standard EN 13697

## **HAZARDS**

Causes serious eye irritation. May cause respiratory irritation. Very toxic to aquatic life with long lasting effects. Wear protective clothing.





IF INHALED: Remove person to fresh air and keep comfortable for breathing.

**IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

Call a POISON CENTRE/ Doctor if you feel unwell. Store in a well-ventilated place. Keep container tightly closed. Store locked up.

For professional use only

Gel-clear Ltd 145 Bolton Road, Darwen, Lancashire, England BB3 1DF

Get in touch: ☎ 01254 760002 | ⋈ info@gel-clear.co.uk | ∰ www.gel-clear.co.uk